



ELECTROSTATIC POWDER COATING EQUIPMENT

-OPERATION MANUAL-

M100 Series

Model: M120





www.irisinco.com

Operating instructions and spare parts list

© Copyright 2013 IRIS
All rights reserved.

Table of contents

Page NO.

| | |
|--|----|
| Instruction Manual | 2 |
| Technical Safety Regulations For Electrostatic Powder Spraying Equipment | 2 |
| Pulse Coating System M-120 | 3 |
| Function Of High Voltage Generation | 3 |
| Circuit | 3 |
| Gun Technical Data | 4 |
| Gun Disassembly Parts | 5 |
| Connection Guide | 6 |
| Control Unit Technical Data | 7 |
| Front & Back Of Control Unit | 8 |
| Top Of Control Unit | 9 |
| Display & Control Board | 11 |
| Injector | 12 |
| Powder Hopper | 14 |
| Filter Regulator | 15 |
| Pneumatic Diagram | 16 |
| Color Change | 16 |
| Maintenance And Cleaning | 17 |
| Troubleshooting | 18 |

ELECTROSTATIC POWDER COATING EQUIPMENT

Instruction Manual

The Manual powder Gun M-100 with High voltage generator is designed to apply electrostatically chargeable powder on grounded work pieces. The gun designed with state of the art of technology. The parts are assembled in a simple manner which guarantees easy maintenance and repair. The guns produce 100KV high voltage and it is therefore absolutely necessary to read the instruction manual carefully before starting to operate.

The manufacturer is not responsible for damage resulting from improper use of this equipment. The end-user alone is responsible. If the IRIS manual coating equipment is to be used for other purposes or other substances outside of our guidelines then it will be out of guarantees.

Important:

The M-120 manual coating equipment should only be used, maintained and started up by trained personnel, who are informed about and are familiar with the possible hazards involved. The powder spraying equipment should only be started up and used once the operating instructions have been carefully studied.

Improper use of the controlling device can lead to accidents, malfunction or damage to the control itself.

Technical safety regulations for electrostatic powder spraying equipment:

- 1-All equipment and parts within a reach of 5m from the spray gun have to be earthed.
- 2-The floor of place that operator is standing have to be conductive.
- 3-The operator has to wear conductive shoes the leather shoes recommended.
- 4-operator has to handle the gun with bare hands or with conductive gloves.
- 5-The earth wire (green/yellow) has to be connected with the earth screw of the electrostatic powder coating unit. The earth wire has to have a solid metallic connection with the booth, the recovery system, the conveyor chain as well as the objects to be coated.
- 6-The electric cables as well as the powder hoses leading to the guns have to be handled in such a way that they are protected against mechanical damage.
- 7-Only when the recovery system has been put into operation the powder coating unit be switched on.

8-Electric wires as well as powder hoses have to be controlled at least once a week.

9-The earth of all conductive parts and equipment within the reach of 5m from the spray area has to be checked at least once a week.

10-The control panel has to be switched off when cleaning the guns or changing the nozzles or extensions.

11-As a general rule for all powder spraying installations, persons with pacemakers should never enter high voltage areas or areas with electromagnetic fields.

12-Each person responsible for the assembly, start-up, operation, service and repair of powder spraying equipment must have read and understood the operating instructions and the “Safety regulations”-chapter. The operator must ensure that the user has had the appropriate training for powder spraying equipment and is aware of the possible sources of danger.

Pulse coating system M-120

- High quality of coating.
- Reduction in coating material consumption.
- Effective coating in corners.
- Effective recoating.
- Decrease in orange peel.
- 3pre programed mode
- Gun and Earth connectivity detector

Function of High voltage generation


The control unit supplies a high-frequency low-voltage signal of approximately 10 V rms. This voltage is fed through the gun cable to the high voltage cascade in the gun body.

In the high voltage cascade, the low-voltage is high-transformed in a first step. This primary high voltage is subsequently rectified and multiplied in the high voltage cascade in a second step, until the required high voltage is obtained at the end (approx. 100 kV). The high voltage is now fed to the electrode within the spray nozzle.

Circuit

In addition to the modulated low voltage needed for high voltage generation, there are signal lines fed troughs the gun cable. The control signals are used for monitoring gun trigger status and gun remote control functions.

The gun is released by a reed switch, which is operated by a magnet in the trigger. The control unit switches the modulated low voltage, powder conveying, and the rinsing air on.




Technical Data:

M-120 Manual Gun

| | |
|----------------------|---------------|
| Length of gun | 340mm |
| Gun weight | 420gr |
| Out put voltage | 100K V approx |
| Max out put current | 140μA |
| Frequency | 32KHz approx |
| Polrity | negative |
| Max powder injection | 500g/min |
| Length of cable | 5m |
| Packing size | 240*320*60 mm |


Disassembly parts



PARTS LIST – A -

| Drawing No. | Part No. | Description |
|-------------|----------|------------------------|
| 1 | 101 | Gun body |
| 2 | 102 | High voltage cascade |
| 3 | 103 | handle |
| 4 | 104 | Trigger cover |
| 5 | 105 | Trigger |
| 6 | 106 | Rod holder with spring |
| 7 | 107 | Nozzle cover |
| 8 | 108 | Gun cap |
| 9 | 109 | Round deflector |
| 10 | 110 | Auxiliary air nipple |
| 11 | 111 | Powder channel |
| 12 | 112 | Cable bracket |
| 13 | 113 | Hook |
| 14 | 114 | Back cap holder |
| 15 | 115 | Back cap |

Connection Guide





| Drawing No. | Description |
|-------------|-----------------------------|
| 1 | Control unit |
| 2 | Manual gun |
| 3 | Input air connection 8 |
| 4 | Feeding air connection 8 |
| 5 | Dosage air connection 6 |
| 6 | Fluidizing connection 6 |
| 7 | Powder hose |
| 8 | Gun connector |
| 9 | Main supply Air |
| 10 | Automizing air connection 4 |
| 11 | Earth |
| 12 | Powder vent hose |
| 13 | Gun holder |

Control Unit


Technical Data :

| | |
|---------------------|----------------------|
| Input Voltage | 220 V AC |
| Output Voltage | Max 100K V |
| Output Current | Max 140 μ A |
| Input Power | Max 65 w |
| Frequency | 50/60 HZ |
| Solenoid Valve | 24v DC |
| Input Air Pressure | 6~8 bar |
| Temp Working | 5~40°C |
| Max Air Consumption | 14Nm ³ /h |
| Size(W*L*H) | 350*270*110 mm |

Front & Back of Control Unit




Top of Control Unit



PARTS LIST – B -

| Drawing No. | Description |
|-------------|-----------------------------|
| 1 | Power Switch |
| 2 | Display & Control board |
| 3 | Air regulator 0~12 |
| 4 | Air regulatot 0~8 |
| 5 | Air regulator 0~4 |
| 6 | Feeding air manometer |
| 7 | Dosage air manometer |
| 8 | Automizing air manometer |
| 9 | Feeding air connector |
| 10 | Dosage Air connector |
| 11 | Main air connector |
| 12 | Automizing Air connector |
| 13 | Ground nut |
| 14 | Fuse holder with Fuse 1 A |
| 15 | Fuse holder with Fuse 2.5 A |
| 16 | Automatic jumper |
| 17 | Main power cable socket |
| 18 | Gun cable socket 3 pin |
| 19 | Solenoid Valve |
| 20 | Transformer |
| 21 | Main P.C.B |

Display & Control Board




| Drawing No. | Icon | Description |
|-------------|------------------|--|
| 1 | + | To Increase Voltage |
| 2 | - | To Decrease Voltage |
| 3 | AUTO | Turn On/Off Automatic Mode |
| 4 | Pulse Power Icon | Turn On/Off Pulse Power Mode |
| 5 | + | To Increase Current |
| 6 | - | To Decrease Current |
| 7 | EXIT | To Exit Program Mode |
| 8 | P | To Select Pre-Programmed Mode |
| 9 | ! | Blinking If Earth Is Not Connected |
| 10 | ⚡ | Blinking If Gun Is Not Connected |
| 11 | A | Indicates That Automatic Mode Is On Or Not |
| 12 | ⏏ | Indicates That Pulse Power Mode Is On Or Not |
| 13 | ☁ | Indicates Recoat Program |
| 14 | ☁ | Indicates Corner Program |
| 15 | ☁ | Indicates Flat Program |
| 16 | 8888 | Working Current |
| 17 | 8888 | Working Voltage |

Injector


The injector is used to convey normal organic powders between the powder hopper and the powder gun. The injector is supplied with a Teflon insert sleeve as standard.

If air flows through the nozzle into the cavity, a vacuum is created in the cavity. This vacuum causes powder to be drawn up the suction tube and into the cavity. A powder/air mixture is created. The forward air velocity at the nozzle conveys the powder/air mixture through to the powder hose to the gun.

The concentration of the powder/air mixture, and with it, the powder output depends on the conveying air pressure and supplementary air pressure, the quality of the powder, the length of the powder hose, the diameter of the powder hose, and the difference in the height between the gun and injector, and the type of nozzle. The condition of the insert sleeve is of great importance, because wear causes the powder output to sink drastically.



1. Remove the injector from the hopper.
2. Pull powder hose off the hose fitting.
3. Clean the hose fitting with compressed air which is free of water and oil.
4. Clean injector body with compressed air which is free of water and oil.
5. Reassemble the injector and fit it on the hopper.



PARTS LIST - C -

| Drawing No. | Part No. | Description |
|-------------|----------|-----------------|
| 1 | 201 | Injector body |
| 2 | 202 | Sleeve |
| 3 | 203 | Sleeve holder |
| 4 | 204 | Air fitting 6 |
| 5 | 205 | Air fitting 8 |
| 6 | 206 | Check valve |
| 7 | 207 | Injector Nozzle |
| 8 | 208 | Pipe holder |
| 9 | 209 | pipe |


Powder Hopper




PARTS LIST – D -

| Drawing No. | Part No. | Description |
|--------------------|-----------------|---------------------------|
| 1 | 251 | Injector |
| 2 | 252 | Powder vent hose |
| 3 | 253 | Hopper body |
| 4 | 254 | Powder cap |
| 5 | 255 | Hopper cap |
| 6 | 256 | Injector holder |
| 7 | 257 | Cap rubber |
| 8 | 258 | Snap lock |
| 9 | 259 | Fluidizing rubber |
| 10 | 260 | Fluidizing plate |
| 11 | 261 | Hopper bottom case |
| 12 | 262 | Fluidizing fitting |

Filter regulator



Pneumatic Diagram



Color change

When a color change takes place, the individual components of the manual coating equipment must be cleaned carefully.

1. Empty the powder hopper and clean thoroughly
2. Clean the powder hose:
 - Strip the powder hose from the hose connection on the injector
 - Point the gun into the booth
 - Blow through the hose manually with a compressed air gun
 - Fit the powder hose again to the hose connection on the Injector
3. Dismantle and clean the powder gun
4. Clean the injector
5. Prepare the manual coating equipment with new powder for start-up

Maintenance and cleaning

Daily maintenance

1. Clean the injector
2. Clean the powder gun
3. Clean the powder hose

Weekly maintenance

1. Clean the powder hopper, the injector and the powder gun
2. Check the control unit grounding connections to the coating booth, the suspension devices of the work pieces, or the conveyor chain

If in disuse for several days

1. Disconnect the mains plug
2. Clean the coating equipment
3. Turn off the compressed air main supply

Cleaning the powder hopper

1. Disconnect the fluidizing air supply
2. Remove the injector
3. Open the cover, blow out with compressed air and clean with a clean dry brush and cloth
4. Clean the suction tube, and injector
5. Empty the remaining powder into a container
6. Clean the hopper with a cloth
7. Reassemble the powder hopper

Troubleshooting

| Fault | Causes | Fault elimination |
|---|---|---|
| Display remains off | AC 220 volt cable connection defective Fuse defective Low voltage transformer defective | Connect the cable to power supply Replace Replace |
| High voltage display not operate | Cascade defective PCB defective Reed switch defective Gun cable defective | Replace Replace Replace check |
| Powder does not adhere to object | Cascade defective PCB defective Object is not grounded | Replace Replace Ground the object |
| Powder does not come out through the gun | Solenoid Valve defective Sleeve deformation Reed switch defective Fluidizing plate defective | Replace Replace Replace Replace |
| Powder output is continuously | Reed switch defective Solenoid valve defective | Replace Replace |
| The powder is not fluidized | Compressed air not present Fluidizing air is set too low | Connect the equipment to the compressed air Set the fluidizing air correctly |
| Powder is pumping | Sleeve deformation Powder hoses are gripped Dosage air is too low | Replace Change the hose Set the dosage air correctly |



- ✓ Acquired CE Mark
- ✓ Acquired ISO 9001:2008

www.irisinco.com

E-mail: info@irisinco.com